Intent – Broadcast and Receive Messages

Note: To set up a broadcast receiver, include the following in the activity from which you want to listen to broadcast:

```
public class MyBroadcastReceiver extends BroadcastReceiver {
    @Override
    public void onReceive(Context context, Intent i) {
        // access the broadcast message through i.getStringExtra("key")
    }
}
```

Note: Include also the following in the activity from which you want to listen to broadcast:

```
MyBroadcastReceiver myReceiver;
IntentFilter myIntentFilter;
```

In the onCreate method, add:

```
myReceiver = new MyBroadcastReceiver();
myIntentFilter = new IntentFilter("SOC_Broadcast");
```

```
Register the receiver in onResume():
```

```
registerReceiver(myReceiver, myIntentFilter);
```

Unregister the receiver in onPause():

```
unregisterReceiver(myReceiver);
```

```
@Override
public void onResume() {
    super.onResume();
    //-- register the receiver ---
    registerReceiver(myReceiver, myIntentFilter);
}

@Override
public void onPause() {
    super.onPause();
    //-- unregister the receiver --
    unregisterReceiver(myReceiver);
}
```

To send a broadcast (can be from a different activity):

```
Intent i = new Intent("SOC_Broadcast");
i.putExtra("key", "some value from intent");
sendBroadcast(i);
```

Can also define a receiver through the AndroidManifest.xml file:

Then define a SecondReceiver class to listen to broadcast:

```
public class SecondReceiver extends BroadcastReceiver {
    @Override
    public void onReceive(Context context, Intent i) {
        // access the received message through i.getStringExtra("key")
    }
}
```

Note: Broadcast receivers registered through AndroidManifest.xml are useful for broadcasts that may go on while your code is not in memory (e.g., BOOT_COMPLETED, scheduled alarms via AlarmManager etc.).

```
To read the status of battery:
                                                                   sticky intent, no
IntentFilter ifilter =
                                                                   need to register a
   new IntentFilter(Intent.ACTION_BATTERY_CHANGED);
                                                                   Broadcast Receiver.
                                                                   Can just pass in a
Intent batteryStatus = this.registerReceiver(null, ifilter);
                                                                   null here
// Is battery charging or full?
                   = batteryStatus.getIntExtra(BatteryManager.EXTRA_STATUS, -1);
int status
boolean isCharging = status == BatteryManager.BATTERY_STATUS_CHARGING ||
                     status == BatteryManager.BATTERY_STATUS_FULL;
// How are we charging the battery?
int chargePlug
                   = batteryStatus.getIntExtra(BatteryManager.EXTRA_PLUGGED, -1);
boolean usbCharge = chargePlug == BatteryManager.BATTERY_PLUGGED_USB;
                   = chargePlug == BatteryManager.BATTERY_PLUGGED_AC;
boolean acCharge
// check battery level
int level = batteryStatus.getIntExtra(BatteryManager.EXTRA_LEVEL, -1);
int scale = batteryStatus.getIntExtra(BatteryManager.EXTRA_SCALE, -1);
float batteryPct = level / (float)scale;
```

because it is a